


Front panel



❶ Power operation button (⏻)

❷ Power indicator

❸ DISC LAYER button

❹ PURE DIRECT button

❺ Remote control sensor

❻ Display

❼ Disc tray open/close button (⏮)

❽ SOURCE button

❾ USB port

❿ Reverse-skip/Forward-skip buttons
(⏮, ⏭)

⓫ Stop button (■)

⓬ Play/Pause button (▶/⏸)

⓭ Disc tray

⓮ SUPER AUDIO CD indicator

⓯ Advanced AL32 Processing indicator