Display

❶ **Tone indicators**

SDB: Lights when the super dynamic bass function is set to “ON”.

TONE: Lights when the tone (bass/treble) is being adjusted.

❷ **Tuner reception mode indicators**

❸ **Information display**

❹ **Timer operation indicator**

❺ **Remote control signal reception indicator**