POLSKI • РУССКИЙ • SVENSKA • NEDERLANDS • ESPAÑOL • ITALIANO • FRANÇAIS • DEUTSCH • ENGLISH

DENON

DRA-F109
STEREO RECEIVER

Getting Started

Erste Schritte / Mise en route / Guida introduttiva / Antes de empezar / Aan de slag / Att komma igång / Начало работы / Skrócona instrukcja obsługi

Welcome

Thank you for choosing a DENON receiver. This guide provides step-by-step instructions for setting up your receiver.

If you have setup problems:

If you need additional help in solving problems, contact DENON customer service in your area.
See the address sheet included in the box.

Before You Begin

What's In the Box

Remote control unit	R03/AAA batteries	Power cord For continental model only / For UK model only	
Receiver		FM indoor antenna For continental model only	DAB/FM indoor antenna For UK model only
Safety Instructions	Getting Started	Owner's Manual	Service network list

Required for setup

Speaker systems	Speaker cables	Audio cable

Required for F109 system connections

DCD-F109 CD player	DNP-F109 Network audio player
Digital coaxial cable (included with DCD-F109/DNP-F109)	System cable (included with DCD-F109/DNP-F109)

Note that the illustrations in this manual is for explanation purposes and may differ from the actual unit.

Setup Steps

There are six steps to the setup process.

1. Install batteries in the remote control unit
2. Connect the speakers
3. Connect the audio devices
4. Connect the power cable
5. Turn the power on
6. Begin playback

1 Installing batteries in the remote control unit

2 Connect the speakers

Connecting the speaker cables

① Peel off about 10 mm of sheathing from the tip, then twist the wire core.

② Loosen the speaker terminal.

③ Insert the speaker cable into the speaker terminal.

④ Tighten the speaker terminal.

3 Connect the audio devices

❑ When making system connections

❑ When making an analog connection

4 Connect the power cable

Connect to household power outlet
(AC 230 V, 50/60 Hz)

5 Turn the power on

6 Begin playback

1 Select the source.

2 Play the source.

3 Adjust the volume.

Owner's Manual

The included CD-ROM contains an Adobe PDF version of the full owner's manual for the receiver.
Please reference this manual for more details about the setup and operation of the receiver and it's features.

1 Insert the disc into your PC.

2 Follow the screen or double click on the PDF file.

DENON

www.denon.com

V00

D&M Holdings Inc.
Printed in China 5411 10870 00AD