Front panel

❶ **Power operation button (⏻)**

❷ **Power indicator**

❸ **PRESET CALL button**

❹ **SOURCE knob**

❺ **Remote control sensor**

❻ **Display**

❼ **Headphones jack (PHONES)**

❽ **VOLUME knob**