DENON®

ENGLISH

FRANÇAIS

ESPAÑOL

AVR-X4300H

INTEGRATED NETWORK AV RECEIVER

Quick Start Guide

Guide de démarrage rapide / Guía de inicio rápido

Read Me First....

Lisez-moi en premier.... / Lea esto primero....

Please do not return this unit to the store.
If you need help…

Check our AVR setup tips online

Usa.denon.com/SetupTips
Ca.Denon.com/SetupTips

Call for Assistance

1-855-MY.DENON (USA) **1-855-693-3666**
1-800-668-0652 (Canada)

Monday – Friday 10:00AM to 10:00PM E.S.T
Saturday 12:00PM to 8:00PM E.S.T

Welcome

Thank you for choosing a Denon AV receiver. This guide provides step-by-step instructions for setting up your AV receiver.

Before You Begin

Required for Setup

TV	Speaker cables	Speakers
HDMI cable	Subwoofer cable	

Optional

LAN cable	or	Wi-Fi router

- When connecting this unit to a device that is compatible with the Deep Color, 4K and ARC functions, use a “High Speed HDMI cable with Ethernet” that displays the HDMI logo.
- These drawings are for illustrative purposes only and may not represent the actual product(s).

What's In the Box

Quick Start Guide		FM indoor antenna	
Safety Instructions		AM loop antenna	
Notes on radio		Sound calibration microphone	
Warranty (for North America model only)		Sound calibration microphone stand	
Cable labels		Remote control unit	
Receiver		R6P/AA batteries	
Power cord		External antennas for Bluetooth/ wireless connectivity	

- The included sound calibration microphone stand is convenient for use when performing Speaker Calibration. Using your own tripod or the supplied Sound calibration microphone stand enables settings to be automatically configured to the optimum listening environment, providing exceptionally high performance.

Important: External Antennas

The removable external antennas are required for both Bluetooth and Wireless network connectivity. Please make sure to connect the antennas before attempting to use the Bluetooth or Wi-Fi features of the AVR-X4300H.

❏ Connecting the external antennas for Bluetooth/Wireless connectivity

For each of the two antennas:

① Place the antenna evenly over the antenna terminal located at the upper left or right corner of the rear panel.

② Turn the antenna clockwise until it is fully connected. Do not over tighten.

③ Rotate the antenna upwards for the best possible reception.



Setup

There are three steps to the setup process.

1. Installing batteries in the remote control unit
2. Connecting the receiver
3. Following the On-Screen Setup Assistant

1 Installing batteries in the remote control unit



2 Connecting the receiver

1) Place the receiver near your TV and connect the power cord



2) Connect the receiver to your home network

Wired LAN

Connect an Ethernet cable (not included) between your receiver and your network router.



Wireless LAN

When connecting to wireless LAN (Wi-Fi), follow the instructions in “Connecting the external antennas for Bluetooth/Wireless connectivity” and connect the antennas.



3) Connect the receiver to your TV with an HDMI cable



ARC (Audio Return Channel) :
If your TV supports ARC, your TV can send audio back to the AV receiver when you are using your TV's built-in video sources (TV tuner, Smart TV streaming services, etc…) ARC requires that you enable HDMI CEC on your TV. Please refer to your TV's Owner's Manual for instructions on how to setup HDMI CEC. Note that some TV manufacturers use other names for the HDMI CEC function.

4) Turn on the TV



TV remote control unit

5) Select the appropriate HDMI input on your TV



TV remote control unit

6) Turn on the receiver

- Press ⏻ to turn on the receiver.



7) Verify the connection

- Verify that you can see this screen on your TV.



If this screen is not displayed, please go back and retry the steps again in the recommended sequence.

3 Following the On-Screen Setup Assistant

The Setup Assistant will walk you through connecting and configuring your speakers and components to your Denon receiver. Please use the remote control and follow the on-screen instructions.





Owner's Manual

- For more information, visit www.denon.com
- Refer to the Online Manual for other functions information and operation procedure details. manuals.denon.com/AVRX4300H/NA/EN/

Online Manual

All New "Denon 2016 AVR Remote" App

The "Denon 2016 AVR Remote" App allows you to remotely control your Denon receiver wirelessly from your iOS, Android, or Kindle mobile devices. Please visit the Apple App Store, Google Play, or the Amazon Appstore and search for "Denon 2016 AVR Remote" to get your free copy.

Download on the App Store

GET IT ON Google Play

Available at amazon

HEOS

This unit is part of the HEOS wireless multi-room sound system that enables you to enjoy your favorite music anywhere and everywhere around your home. By utilizing your existing home network and the HEOS App on your iOS, Android or Kindle mobile devices, you can explore, browse, and play music from your own music library or from many online streaming music services.

- True multi-room audio - play different songs in different rooms or the same song in every room
- Industry leading microsecond audio synchronization between HEOS device

Getting the “HEOS“ App

Please visit the Apple App Store, Google Play, or the Amazon Appstore and search for “HEOS” to get your free copy.

Download on the App Store

GET IT ON Google Play

Available at amazon

DENON®

www.denon.com

Printed in Vietnam 5411 11387 00AD
Copyright © 2016 D&M Holdings Inc. All Rights Reserved.